


**LASER PRESENTER  
MP-1922  
USER'S MANUAL**



**INTRODUCTION**

The MP-1922 Wireless Powerpoint Presenter is a great tool for professional presentation with Microsoft PowerPoint. You no longer need to stay next to your computer for clicking the keys while making presentation or have an addition person click the slides for you. The Page up & down and volume +/- function expands the control of your PC for more versatile operation. Walk freely around the room and focus on your presentation instead!

**LIST OF FEATURES**



1. Power Switch : Turns the Laser Presenter On/Off
2. Battery Compartment: Holds one AAA battery
3. USB Receiver : Receives signal from Laser Presenter
4. Laser Aperture : Emits laser beam
5. LED indicator: Indicates working status  
Low battery: Battery needs to be replaced, when LED flashes slowly after pressing PgUp/PgDn button. (LED indicator doesn't light up when battery has sufficient power)
6. Hyperlink: Press to select the hyperlink / switch over different links (only


useful in the full screen mode); short double press to start Enter function and open the hyperlink.  
Long press: switches window

7. PgUp: Short Press: Page up;  
Long Press: Full screen/ESC
8. PgDn: Short Press: Page down;  
Long Press: Black screen/ESC (only in full screen mode)
9. Laser Button: Press to emit laser beam and release to turn off
10. Pocket Clip: Fix the Presenter in your pocket
11. Volume +/-: Turns volume up or down when playing audio or video files

Note : Only Page Up, Page Down, Play/ESC and Black Screen functions work in Mac OS Keynote software, but not the hyperlink function.

**INSTALLING BATTERY & USB RECEIVER**

- Open the battery compartment cover and place an AAA battery then close it.



- Ensure the battery polarity (+) (-) is correct.
- Please remove the battery if the device will not be used for a long period of time.

**OPERATING THE WIRELESS PRESENTER**

**INSTALLATION**

1. Pull the Mini USB receiver from the end of the Presenter.
2. Plug this receiver into the USB port on your laptop or PC.
3. The system will automatically detect the device and search for the driver to complete the setup. This may take a few minutes for initial setup.

**OPERATION**

1. Switch the Power button from OFF to ON, and the LED indicator blinks twice indicating the presenter is ready to go.
2. Open Microsoft PowerPoint or Keynote and select the file for presentation.
3. Refer to the button features to operate; Page Up, Page Down, Full Screen, Black Screen and Hyperlink.

**Note**

1. The Laser Presenter will enter into Sleep mode automatically when there is no activity for a while, and wakes up by pressing any button.

2. The transmission distance between the USB receiver and Laser Presenter may be decreased by interference from electronic devices around.
3. Turn off the Laser Presenter after use.
4. Please insert the USB receiver back into the Laser Presenter and turn Off the Power switch in order to prevent damage caused by the buttons being accidentally pressed.

**OPERATING THE LASER POINTER**

Turn ON the Power switch & Press the Laser button, the laser beam will be emitted from the aperture.

**CAUTION:**

1. Do not stare into the laser beam.
2. Do not direct the beam towards a person's eyes.
3. Remove the battery if the Presenter is not used for a long period of time.
4. Do not attempt to disassemble or repair.

**Troubleshooting**

Problem	Possible Cause	Solutions
No laser beam	Battery failure	1. Make sure the battery is installed with correct polarity. 2. Power too low, replace with new battery.
Does not recognize USB receiver	USB interface failure	Make sure that USB interface is functioning. Try other USB interfaces as well.
Laser beam is working, but other features are not working-	Laser Presenter and receiver do not connect	Contact your local dealer.

Do not try to disassemble the Laser Presenter by yourself. Doing so will void your warranty and may aggravate the problem.

**PRODUCT SPECIFICATIONS**

Technology	Radio Frequency
Frequency	2.4GHz, up to 30 meters
USB Interface	USB 3.0 / 2.0 / 1.1
Laser Power	Class IIIa (5mW max.)
Wavelength	650nm (Red)
Battery	AAA battery x 1
Dimensions	139 (L) x 18 (W) x 19 (H) mm
Weight	33g including battery
OS Supported	WinXP, Win 7/8/10, Linux MAC OS, Android 4.0 or later
Voltage	1.5 V

Trademarks as mentioned are properties of their respective owners