

CAUTION:

1. Do not stare into the laser beam.
2. Do not direct the beam towards a person's eyes.
3. Remove the battery if the Presenter is not used for a long period of time.
4. Do not attempt to disassemble or repair.



OPERATING THE LASER POINTER

Press the On/Off push button and the laser beam will be emitted from the aperture.

Operating Tips

- First, point at the object or information to be highlighted, then switch on the laser by the laser button. Align the spot.
- Do not keep switched on for more than a few seconds in order to keep attention. Repeated presses will emphasize a point.
- Use only occasionally to maintain high impact.

PRODUCT SPECIFICATIONS

Technology	Radio Frequency
Frequency	2.4GHz
Control Distance	>20m
Laser Power	Class III (5mW max.) or Class II (1mW max.)
Wavelength	650nm
Battery	AA battery x 1
Dimensions	142(L) x Dia.17 mm
Weight	49g including battery
Operation System	Windows 2003, Windows 7/8/10, MAC OS, Android
USB Version	USB 2.0

Trademarks as mentioned are properties of their respective owners

OPERATING THE POWERPOINT PRESENTER INSTALLATION

1. Rotate to remove the Mini USB receiver from the end of the Presenter.
2. Plug this receiver into the USB port on your laptop or PC.
3. The system will automatically detect the device and search for the driver to complete the setup. This may take a few minutes for initial setup.

OPERATION

1. Open Microsoft Powerpoint and select the file for presentation.
2. Press the "Page Up" or "Page Down" button to go forward and backward to get to different slides.
3. Press and hold the "Page Up" button for 2 seconds will play slides from the current page. Press and hold the same button for 2 seconds again will escape from this full screen mode.
4. Press and hold the "Page Down" button for 2 seconds will blacken the screen. Press and hold the same button for 2 seconds to exit black screen and return to the presentation.

Troubleshooting

Problem	Possible Cause	Solutions
No laser beam	Battery failure	1. Make sure the battery is installed with correct polarization. 2. Power too low, replace with new battery.
Does not recognize USB receiver	USB interface failure	Make sure that USB interface is functioning. Try other USB interfaces as well.
Laser beam is working, but other features are not work	Wireless presenter and receiver do not connect	Contact your local dealer.

Do not try to disassemble the Wireless Presenter by yourself. Doing so will void your warranty and may aggravate the problem.


WIRELESS PRESENTER MP-1923 USER'S MANUAL



INTRODUCTION

The MP-1923 Wireless Powerpoint Presenter is your ultimate partner for State-of-the-Art presentations. You can move around and interact with your audiences while still maintaining control of your laptop or PC. The laser pointer allows you to highlight your message from a distance.

LIST OF FEATURES



1. Laser Beam Aperture
2. Laser On/Off Button
3. Page Up or "Press and Hold" to Play Powerpoint
4. Page Down or "Press and Hold" to Black Screen
5. Battery Compartment
6. USB Receiver

INSTALLING BATTERY

- Rotate to remove the battery cover.



- Insert one AA battery with the smaller (+) terminal facing the opening of the battery compartment.
- Replace and rotate the battery cover.